




# EMERALD HAMMER LED GROW LIGHT

## Installation Instructions & User Manual



When using electrical equipment, basic safety precautions should always be followed:

Read all instructions carefully before use, service should be performed by qualified personnel.

Make sure all connections are in accordance with the National Electrical Code and local regulations.

To avoid possible electric shock, be sure the power supply is turned off before servicing or installing

Instructions may not cover all details. For additional information, please contact Arden Lighting Tech.






## Parts Enclosed

- A - LED grow-light\*
- B - Extension Cord
- C - Screwdriver

*\*For EH500L Models, UL Required LED lens covers will be installed*

*Hangers not supplied*



## Instructions For Use

**Do not place light facing LEDS down on any surface, damage can result**

1. Completely remove grow-light from packaging before use
2. For EH500L, remove protective plastic film from clear lenses
3. Ensure fixture is hung safely (hang only from hanger holes)
4. To power up, connect to any grounded 120v outlet
5. For dimming instructions, please see sheet 3
6. For EH500L Models - clean lens with microfiber cloth only



## Dimming Instructions

**Light is set to maximum output at factory, dimming is controlled by adjusting driver current**


1. Carefully pop out rubber plug labeled "Io ADJ." (do not adjust "Vo ADJ.")
2. Adjust inner screw with included screwdriver
3. Once desired light output is achieved, re-insert rubber plug

### Care should be taken when using dimming feature:

Adjustment screw can be stripped easily, turn no more than 270°

Insure to not damage rubber plugs when removing

Do not adjust voltage or light will not function correctly, if it is mistakenly moved turn adjusment screw fully clockwise





## Product Specs

